



Model No:666 Product size: 13x13x19.6cm N.W: 420g
Power Supplyment: 2pcs AAA battery Rated Power: 1W
Rated Voltages: 3V



DESKTOP SMART TRASH CAN USER MANUAL

Installation and usage instruction

Step 1: Battery Installation


1. Install 2pcs AAA battery



1. Slide open the sensor lid manually.




2. Open the cover of the battery case and install AAA batteries into battery case according to "+-." instruction.



3. Close the cover of the battery case tightly. Once switch on, the facial expression will light on and the lid will automatically close after 3s.

Step 2: Instruction of sensor function



Sensor area is located in obliquely above dark spherical display. When any objects approach the sensor area around 0-15cm, the sensor lid will open automatically and logo will light on and flash. Meanwhile glasses frame icons lights on. After leaving sensor area, sensor lid will close automatically after 5s, at same time, smiling face icons lights on and it lasts around 2s, then trends volume icons flash and lasts 5s.

Installation and Usage Instruction

Anti-pinching Instruction



During close process, when lid encountered obstacles, it will re-open and close after 2s.

Multiple facial expressions



Open



Close



Interactive
indictor



Low battery
indictor

Low battery indicator

When capacity of the the battery is near empty, ZZ icons will show in sensor process and display screen will light on and flash ZZ icon per 30 minutes in standby status(No open and close action of sensor lid during the standby Period).



Model No:666 Ürün boyutu: 13x13x19.6cm
Güç Kaynağı: 2 adet AAA pil Nominal Gerilimler: 3V
N.W: 420g Nominal Güç: 1W



MASAÜSTÜ AKILLI ÇÖP KUTUSU KULLANIM KILAVUZU

Kurulum ve kullanım talimatı

Adım 1: Pil Kurulumu


1. 2 adet AAA pil takın



1.Sensör kapağını manuel olarak kaydırarak açın.




2. Pil kutusunun kapağını açın ve AAA pilleri "+-." talimatına göre pil kutusuna takın.



3. Pil kutusunun kapağını sıkıca kapatın. Açıldığında, yüz ifadesi yanacak ve kapak 3 saniye sonra otomatik olarak kapanacaktır.

Adım 2: Sensör fonksiyonunun talimatı



Sensör alanı, koyu renkli küresel ekranın üzerinde eğik olarak yer almaktadır. Herhangi bir nesne sensör alanına 0-15 cm civarında yaklaştığında, sensör kapağı otomatik olarak açılır ve logo yanar ve yanıp söner. Bu arada gözlük çerçevesi simgeleri yanar; Sensör alanından ayrıldıktan sonra, sensör kapağı 5 saniye sonra otomatik olarak kapanır, aynı zamanda gülüm yüz simgeleri yanar ve yaklaşık 2 saniye sürer, ardından trend ses seviyesi simgeleri yanıp söner ve 5 saniye sürer

Kurulum ve Kullanım Talimatı

Sıkışma Önleyici Talimat



Kapatma işlemi sırasında, kapak engellerle karşılaştığında, 2 saniye sonra yeniden açılacak ve kapanacaktır.

Çoklu yüz ifadeleri



Aç



Kapat



İnteraktif
Gösterge



Düşük pil
göstergesi

Düşük pil göstergesi

Pil kapasitesi boşa yaklaştığında, sensör işleminde ZZ simgeleri gösterilecek ve ekran yanacak ve bekleme durumunda her 30 dakikada bir ZZ simgesi yanıp sönecektir (Bekleme Süresi boyunca sensör kapağının açma ve kapama eylemi yoktur).