


445mm

TOPMOUNT STAINLESS STEEL KITCHEN SINK Installation & Care Instructions & Cutout Template



- PART LIST**
- Cutout Template
 - Mounting Hardware
 - Bottom Grid
 - Strainer
 - Cutting Board
 - Dish Drying Roll-Up Rack
 - Colander

BEFORE YOU START



- We recommend that all topmount sinks be installed by an experienced, professional installer.
- **IMPORTANT:** The cabinet must be installed, secured, plumbed, and level. Failure of this step can result in product damage.
- Our topmount sinks should only be fastened to a solid surface countertop.
- Make sure that you have all necessary parts by checking the part list.
- We are not responsible for sink or countertop damage caused during installation. Inspect the sink prior to installation to make sure that it has not been damaged.
- Metal edges may be sharp - Extreme care should be taken when handling.
- Follow all local plumbing and building codes.

RECOMMENDED TOOLS

- Tape Measure
- Safety Goggles
- Painters Tape
- Level
- Framing Square
- Pencil (not permanent marker)
- Scissors
- Drill
- Jigsaw
- Phillips Screwdriver
- Screwdriver
- Shims or Cabinet Fillers
- Denatured Alcohol
- Construction Adhesive
- Silicone Sealant

PREPARE THE COUNTERTOP

1. Position the cut-out template front to rear so the sink will not interfere with the cabinet; secure with tape.
2. Trace the template on countertop with a pencil. Dry fit the sink to verify the measurements.
3. Following the countertop manufacturer's instructions, carefully cut the countertop on the inside of the traced line.



Note: Make sure clearance is suitable for backsplash, faucet, and plumbing for the sink




Note: Use the appropriate saw that best fits your countertop material.

IMPORTANT: The cabinet must be installed, secured, plumbed, and level BEFORE installing the sink.

INSTALL THE COUNTERTOP

1. Clean the top of the countertop and the bottom flange (or lip) of the sink with denatured alcohol.

2. Apply a narrow bead of silicone adhesive sealant evenly all around the top edge of the countertop.
3. Position and align the sink over the countertop opening. Carefully lower the sink into the cutout in the countertop. Press silicone onto countertop.



4. Assemble the mounting bracket and fastener. Bend left side of the mounting bracket over to the most (as shown in picture).
5. From the underside — place the mounting bracket in each hole, the fastener head is facing/supporting countertop underneath, and the bending part of mounting bracket is against the sink.
6. Tighten fasteners until mounting brackets are snug against sink. Check alignment of sink to the countertop opening.
7. Tighten down fasteners evenly. Be careful not to over-tighten.
8. Immediately remove excess sealant.
9. Immediately clean and dry the sink after installation.

SUGGESTED MAINTENANCE

- Rinse thoroughly after each use. Clean your sink on regular basis with warm soapy water. Rinse the sink after using cleaning products.
- Wipe the sink surface with a soft cloth after each use to prevent mineral deposits from building up on the surface of the sink. Water quality can affect the appearance of your sink. Frequent and weekly cleaning will prevent discoloration or unsightly film from developing on the finish.
- Always use our sink bottom grid to protect your sinks finish.
- Clean the sink once a week. Be sure to clean in the direction of the satin finish lines, using a cleanser we recommend.
- For a gleaming finish: Polish your stainless steel sink by applying dry flour to the surface. Rub the flour in with a soft cloth, then rinse and dry or dip the sponge in your sink, pour some club soda in and rub with a soft cloth. Dry with a different soft cloth to prevent water spots and surface rust.
- Do not cut food directly on the surface of the sink. Do not leave sharp objects on the surface of the sink for an extended period of time. Do not use abrasive cleaning products, sanding tools, steel wool, or bleaching products.

Note: ANY stainless steel sink can show rust if steel wool pads are used on it. Steel wool or metal scouring pads should never be used to clean your sink as they will leave a residue of small iron particles. They may not be readily visible, but they will lead to staining and corrosion of the sink. If it happens, you can scrub the rusty spot properly by a nylon scrubber.

CAUTION

- Don't rub the sink across the satin finish lines. Scouring across the satin finish lines can damage the original sink finish.
- Don't allow soap or other household cleansers to dry on the surface of the sink. Most brands contain chemical additives which will affect the original finish.
- Don't use solutions of chlorine bleach and water in the sink. Chlorides, which are found in most soaps, detergents, bleaches, and cleansers, are very aggressive to stainless steel. If left on the sink too long, they can cause surface pitting.
- Don't leave wet sponges, cloths, or cleaning pads on the sink. This can lead to surface rust.
- Don't use a steel wool pad to clean your sink. If a more abrasive product is needed, use a green scotch-brite™ pad, being sure to rub in the direction of the satin finish lines. Steel wool pads have a tendency to break apart and small particles of steel can become embedded in the surface of the sink. The steel particles will rust and will give the appearance that the sink itself is rusting.

• Don't use rubber mats or dishpans in the sink. Leaving rubber mats or dishpans in the sink can lead to surface rust or possible pitting. However, if you insist on using mats or dishpans, please remove them after each use and rinse thoroughly.

LIMITED WARRANTY

Our product has been manufactured and tested to the highest quality standards. We offer our customers thoughtfully crafted fixtures & accessories, engineered for enduring performance over years of use.

WHAT IS COVERED BY THE WARRANTY

This warranty extends to the original purchaser only. This warranty is not transferable, between homes or owners and is only applicable to residential use.

WHAT IS NOT COVERED BY THE WARRANTY

We warrant this product against defects due to material or craftsmanship error during the warranty period. We will provide replacement parts at no charge, or at customer's option, replace any product or part of the product that is deemed defective under normal installation, use, service and maintenance. If we are unable to provide a replacement and repair is not practical or cannot be made in timely fashion, we may refund the purchase price in exchange for the return of the product.

RESTRICTIONS

Like other home fixtures, our products will require light maintenance to ensure proper function. We provide you with complete knowledge to perform this maintenance and can also recommend resources if you are unable to fulfill this service. Please read your care and maintenance documentation to determine the limits of proper use.

The original sales receipt, order number, and/or proof of purchase must be presented at the time of the warranty claim, without exception, for this warranty to be applied to all our products.

• This warranty does not cover antedivian, discontinued, or display products, whether such items are purchased at discount outlets, unauthorized dealers, and/or sold on clearance.

• This warranty does not cover instances of negligence, misuse, abuse, improper installation, carelessness, accident, hard water or mineral deposits, exposure to corrosive materials, misapplication, damages caused by improper maintenance, alteration of the product, or failure to follow care or installation instructions enclosed with your product. Avoid using abrasive cleaners such as powders, bleach, ammonia, alcohol or chlorine. Avoid using abrasive pads, steel wool, or wire brushes, as these will damage and wear down the finish.

• This warranty does not apply to Products that have not been installed or operated in accordance with instructions supplied by us and all applicable rules, regulations, and legislation pertaining to such installations.

• This warranty does not apply unless our product is installed by a fully insured and licensed trade professional. We insist that such professionals have experience in the installation of bathroom and kitchen manufactured goods.

• This warranty does not cover labor charges or costs of removal and reinstallation of said product. This warranty does not allow recovery of incidental or consequential damages, such as loss of use, delay, property damage, or other consequential damages, and we accept no liability for such damages.

• Due to the nature of drain usage, there is no finish warranty on any drain product (including pop-up drains, lavatory drains, and kitchen drains).

• This warranty does not cover Marine or Outdoor Installation.

• Except as otherwise provided above, we make no warranties, expressed or implied, including warranties of merchantability and fitness for a particular purpose, or compliance with any code.

• Shipping charges will be covered for the first (1) year of the warranted replacement part or product (U.S. and Puerto Rico shipping charges may apply). International shipping fees are not included.

COMMERCIAL WARRANTY


We extend the above warranty for a period of one (1) year to purchasers of products for industrial, commercial, and business use.

OTHER WARRANTY

By the purchase and use of our products, you agree that we are not liable for incidental, consequential or special damages associated with the return, replacement, installation or use of our product. This includes freight costs, cartridge replacement, labor, travel time, lost profit, home damage and other contingent liabilities and costs (including, without limitation, costs associated with experts, investigations, analyses, attorneys and other professionals and services).

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty extends to the original purchaser and first consumer.

ÜSTTEN MONTAJLI PASLANMAZ ÇELİK MUTFAK EVYESİ Kurulum ve Bakım Talimatları & Kesim Şablonu



- PARÇA LİSTESİ**
- Kesim Şablonu
 - Montaj donanımı
 - Alt zıvara
 - Süzgeç
 - Bulguncak kurutma rulo rafı
 - Kesme tahtası
 - Keçevir

BAŞLAMADAN ÖNCE

- Tüm isten montajı bavatolun deneyin, profesyonel bir montajcı tarafından monte edilmiş bavya ediniz.
- **ÖNEMLİ:** Dolap monte edilmek, sabitlenmek, şakülünde ve ölçülerinde. Bu işlem edilmemesi ürünün hasar görmesine neden olabilir.
- Üstten montajı ayarlamak yalnızca sert yüzeyli bir tezgaha yapılmalıdır.
- Parça listesinde kontrol edilmek gerekli tüm parçaları sohbte olduğunuzdan emin olun.
- Kullanım sırasında hasar gören lavabo veya tezgahın sorunlu olduğu, hasar görmeinden emin olmak için kurulumdan önce evveyi kontrol edin.
- Metal kenarlar keskin olabilir - Kullanırken çok dikkatli davranınız.
- Tüm yerel sağlık tesisat ve bina yönetmeliklerine uygun işlem yapınız

ÖNERİLEN ARAÇLAR

- Şerit Metre
- Güvenlik Gözlüğü
- Boyacı Bandı
- Terazı
- Kurşun kalem (kalıcı keçeli kalem değil)
- Makas
- Matkap
- Testere
- Tornavida
- Şimlir veya Dolap Dolguları
- Denatüre Alkol
- İnşaat Yapıştırıcısı
- Silikon Mastik

TEZGAH HAZIRLAYIN



1. Kesim şablonunu önden arkaya doğru yerleştirin, böylece evye dolaba engel olmaz; bantla sabitleyin. **Not:** Bölgenin su sıçraması, musluk ve lavabo tesisatı için uygun olduğundan emin olun.
2. Şablonu bir kalemle tezgah üzerine yerleştirin. Ölçüleri doğrulamak için evveyi kuru olarak yerleştirin.
3. Tezgah üreticisinin talimatlarını izleyerek, tezgah iten çizginin iç tarafından dikkatlice kesin. **Not:** Tezgah malzemesine en uygun testereyi kullanın. **ÖNEMLİ:** Evyenin montajından ÖNCE dolap monte edilmeli, sabitlenmeli, şakülünde ve ölçüde olmalıdır.



TEZGAH MONTE EDİN

1. Tezgahın üst kısmını ve evyenin alt flanşını (veya dudakları) denatüre alkol ile temizleyin.

2. Tezgahın üst kenarının her tarafına eşit şekilde dar bir silikon yapıştırıcı sürün.
3. Lavaboya tezgah açılığının üzerine yerleştirin ve hizalayın. Evveyi dikkatlice tezgahtaki oyulmuş içine indirin. Silikonu tezgahın üzerine bastırın.
4. Montaj braketini ve bağlantı elemanının önceden monte edin. Montaj braketinin sol tarafını en fazla büyük (resimde gösterildiği gibi).
5. Alt taraftan - montaj braketini her diğale yerleştirin, bağlantı elemanı kafas altındaki tezgaha bacak / destekleyecek ve montaj braketinin bükülen kısmı / destekleyecek şekilde.
6. Bağlantı elemanlarını, montaj braketleri evveye tam oturana kadar sıkın. Evyenin tezgah açılığına hizalandığını kontrol edin.
7. Bağlantı elemanlarını eşit şekilde sıkın. Aşırı sıkılmaya dikkat edin.
8. Fazla süzümazlık maddesini hemen çıkarın.
9. Montajdan sonra evveyi hemen temizleyin ve kuruyun.



Evvede kaucuk matlar kullanmayın. Lavaboda kaucuk matlar bırakmak yüzeyin paslanmasına veya oluşu çakırlanmaya neden olabilir. Bununla birlikte, mat kullanılmaya israr ediyorsanız, lütfen her kullanımdan sonra bunları çıkarın ve iyice durulayın.

ÖNERİLEN BAKIM

- Her kullanımdan sonra iyice durulayın. Evyenizi düzenli olarak akı sabunlu su ile temizleyin.
- Temizlik ürünleri kullanmadan önce evveyi durulayın.
- Evye yüzeyinde mineral birikimlerini çıkarmaya önermek için her kullanımdan sonra evye yüzeyini yumuşak bir bezle silin. Su kalınlığı evyenin görünümünü etkiler. Halka ile kurulum ve halka temizlik, yüzeyde renk değişikliği veya çirkin bir film oluşmasına neden olabilir.
- Evye kaplamasını korumak için her zaman evye alt kaplamasını kullanın. Evveyi hafızda bir kez temizleyin. Önerdiğimiz temizleyiciler kullanmak sadece kaplama çizilme yönünde temizledikten sonra emir duyun.
- "Pati jeli" bir yüzey için: Paslanmaz çelik evyenizi yüzeye kuru un uygulayarak parlatın. Unu yumuşak bir bezle ovalayın, ardından duşun ve kuruyun veya ıspanaklı bulağıyla yıkayın, içine biraz soda ekleyin ve yumuşak bir bezle ovalayın. Su birikimini ve yüzey paslanmasını önlemek için baskın bir yumuşak bezle kuruyun.
- "Yıpacıkları" doğrudan bulağın yüzeyinde kullanmayın. Keskin nesneleri lavabonun yüzeyinde uzun süre bırakmayın. Aşındırıcı temizlik ürünleri, ampas, alüminyum, çelik yüzü veya ağırlık kullanmayın. **Not: HERHANGİ bir paslanmaz çelik evye, keskin çelik yüzü ped kullanılması pas gösterebilir.** Çelik yüzü veya metal ovala pedleri, küçük demir parçacıklardan oluşan bir kalıntı bırakıldığından bulağın yüzeyine pas oluşturabilir. Bu kalıntı kalıplaşabilir, ancak bulağın paslanmasını ve koronaya uğratmasına yol açacaktır. Böyle bir durumda, paslı notayı naylon bir ovucu ile duşun ve paslağı temizleyin.

DİKAT

- Evyenin satın kaplama çizgileri boyunca ovalayın. Satın kaplama çizgileri boyunca ovamak orijinal evye kaplamasına zarar verebilir.
- Sabun veya diğer ev temizleyicilerinin evye yüzeyinde kurumasına izin vermayın. Çoğu marka, orijinal çilay etkileyecek kimyasal katkı maddeleri içerir.
- Evyenin kloşu açtırdı ve su çeşitliliği kullanmayın. Çoğu sabun, deterjan, açtırdı ve temizleyicide bulunan koruyucu paslanmaz çelik için koruyucu. Lavaboda çok uzun süre bırakılma yüzeyde çukurlanmaya neden olabilir.
- İslak süngerler, bezleri veya temizlik pedlerini evyenin üzerinde bırakmayın. Bu yüzey pasına yol açabilir.
- Evyenizi temizlemek için çelik yüzü ped kullanmayın. Daha aşındırıcı bir ürün gerekiyorsa, yeşil

Scotch-Brite™ pedi ve benzerlerini kullanın ve satın kaplama çizgileri yönünde ovaladığınızdan emin olun. Çelik yüzü pedlerin parçalanma eğilimi vardır ve küçük çelik parçacıkları evyenin yüzeyine gömülebilir. Çelik parçacıklar paslanacak ve evyenin kendisini paslandırdığı görüntüsünü verecektir.

SINIRLI GARANTİ

Ürünümüzün en yüksek kalite standartlarına göre üretilmiş ve test edilmiştir. Müşterilerimize, yaygın kullanım için kalite performans için tasarlanmış, özenle hazırlanmış armatürler ve aksesuarlar sunuyoruz.

KİMLER GARANTİ KAPSAMINDADIR

Bu ürünü, garanti süresi boyunca malzeme veya işçilik hatasından kaynaklanan kusurlara karşı garanti ediyoruz. Normal kurulum, kullanım, servis ve bakım koşullarında kusurlu olduğu düşünülen herhangi bir ürünü veya ürün parçasını ücretsiz olarak veya müşteri temsilcisine bilgi olarak değiştireceğiz. Değişim sağlanamaz ve onarım zamanında yapılmazsa, satın alma bedelinin KISITLAMALAR kapsamında iade edilebilir.

DİĞER EV ARMATÜRLERİ GİBİ, ürünümüz de duşun çalışmasını sağlamak için hafif bakım gerektirecektir. Bu garantinin tüm ürünlerimizde uygulanabilmesi için garanti talebi sırasında orijinal satış makbuzu, sipariş numarası veya satın alma belgesi istenmesi olarak biraz edilebilir. Bu garanti, üretimi durdurulmuş veya tehir ürünlerini kapsamaz.

• Bu garanti ihmal, yanlış kullanım, kötüye kullanım, yanlış kurulum, dikkatsizlik, kaza, sert su veya mineral birikimlerle, ajandırı malzemelere maruz kalma, yanlış uygulama, yanlış bakımından kaynaklanan hasarlara, ürünün değiştirilmesi veya ürününüzde birlikte verilen bakım veya kurulum talimatlarına uyulmaması durumlarını kapsamaz. Tozlar, camgır suyu, amonyak, alkol veya kloş gibi aşındırıcı temizleyiciler kullanılmaktan kaçının. Aşındırıcı pedler, çelik yüzü veya tel fırçalar kullanılmaktan kaçının, bunlar çilaya zarar verir ve aşındırıcı.

o Bu garanti, taraftan sağlanan talimatlara ve bu tür kurulumlara ilişkin tüm geçerli kurallara, düzenlemelere ve mevzuata uygun olarak kurulmuş veya değiştirilmiş ürünler için geçerli değildir. Bu garanti, ürünümüzün tam sigortalı ve lisanslı bir ticaret uzmanı tarafından kurulmuş olduğu sürece geçerli değildir. Bu tür profesyonellerin banyo ve mutfakta üretilen ürünlerin kurulumunda deneyimli sahibi olmadığınızdan şüphelenin.

o Bu garanti, işçilik ücretlerini veya söz konusu ürünün sökülmesi ve yeniden takılması masraflarını kapsamaz. Bu garanti, kullanım kaybı, gecikme, maddi hasar veya diğer dolaylı hasarlar gibi arazi veya diğerli hasarlardan sorumlu değildir ve bu tür hasarlar için hiçbir sorumluluk kabul etmeyiz. Drenaj kullanımını doğrudan gereği, herhangi bir drenaj ürününde (açılır drenajlar, lavabo drenajları ve mutfak drenajları dahil) birisi garanti yoktur.

o Bu garanti denizcilik veya DY mekan kurulumunu kapsamaz.

TİCARİ GARANTİ

Yükarıdaki garantiyi, endüstriyel, ticari ve iş amaçlı kullanımı için ürün satın alanlara bir (1) yıllık bir süre için uzatıyoruz.

DİĞER GARANTİ

Ürünümüzün satın alarak ve kullanılarak, ürününüzün iadesi, değiştirilmesi, kurulumu veya kullanımı ile ilgili arazi, dolaylı veya özel hasarlardan sorumlu olduğumuzu kabul edersiniz. Buna nakliye masrafları, kurtarıcılığın, işçilik, seyahat süresi, kar kaybı, ev hasarları ve diğer olası yükümlülükler ve masraflar (uzunluk, arızalar, analizler, avukatlar ve diğer profesyoneller ve hizmetler) ilgili masraflar dahil ancak bunlarla sınırlı olmamak üzere) dahildir. Bu garanti, ilk alıcı ve iküleciler için geçerlidir.

725mm