

Safe, comfortable, graceful, portable  
Wider frame, suitable for baby from birth to 3 years old.  
Adjustable backrest.  
Convenient one-touch-brake  
Aluminum frame  
With easy equipment to remove front and rear wheels.  
With good suspension function for front and rear wheels.  
Easy fold and smaller package  
6-position conversion seats



**BONN**

Huggy Bonn Travel Sistem  
Bebek Arabası



**Components**

**WARNING**

Keep all the plastic bags and small components away from the child to avoid possible suffocation and injury.



12" rear wheels(2 wheels)



8" front wheels(2 wheels)



Seat



Make sure the stroller frame hook is unlocked before using

**Open the frame**

**Notice** Before assembling and using, check the stroller if there is any damaged hardware, loosen joints, missing parts or sharp edges. DO NOT use if any parts are missing or broken.



(1) Place your right foot on the rear wheel axle tube to stabilize the stroller as you lift the handle bar. Lift the handle until you hear an audible "click" to indicate the frame is locked in position.  
(2) Close the safety lock as picture shows.

**Rear wheels assembly**



Lift the stroller rear axle tube and insert rear wheel axle until you hear an audible "click" to indicate the wheel is locked into position. Repeat for the second wheel



**Operation of the safety Harness**



The stroller is equipped with a 5-point safety restraint harness for securing your child in the seat.

When using this stroller, to ensure your child's safety, make sure the safety buckle is locked. Adjust the length of the safety belt to make your child comfortable.

**Using safety belt**



Please central buckle through loop in crotch strap. Clip buckle parts together to secure child. Ensure shoulder straps are locked to central buckle when hears "CLICK"

Please press the central red button, pull out left and right clip buckle parts then slide away two upper buckle to open belt.

**To fold the stroller**



Open the frame safety lock. Pull up the black frame lock with both hands



The hinge must open for folding the stroller frame



Push down the handle bar to fold the stroller.

**Front wheels assembly**



Front wheel assembly: Lift the stroller front axle tube and insert front wheel axle. Press the button simultaneously. Push up until you hear an audible "click" to indicate the front wheel is locked into position. Repeat for the second wheel.

To fix the direction of the front wheels, align front wheels in a straight front position and press down the front wheel lock.

Lift up the front wheel lock, the direction of the front wheels can be universal.

**Adjusting the handlebar**



To adjust the handlebar, press the buttons on both sides of the handlebar.



**Seat Installation**

Surround the stool rod with straps and lock the snap fastener, make sure it is locked tightly when you use the stroller. Show as above photos.



The three buckles must be always closed and fastened, whenever you use the seat on this stroller. Show as above photos.

**Seat Installation**



Install the seat to the frame. Make sure the seat pivot latches on both sides are locked simultaneously into the frame seat posts until you hear an audible "click"

(1) Press the above big buttons on both sides to adjust the seat position.  
(2) Press the below small button on both sides. Lift up the seat till the seat is removed from the frame.

**Seat Rear-facing/forward-facing, Six positions.**




**WARNING**

To avoid injury, never attempt to remove or adjust seat while child is occupying seat.

**To adjust the seat to the position for sleeping**



Open the three buckles under the bottom of the seat, show as photos. Adjust the seat to horizontal position, as shown in the pictures.



Please press red slip buckle to adjust length of belt rope. Repeat for the other side.

Slide buckle and elongate or shorten tail belt to adjust the belt length.

**Using the brakes**



Press the rear wheel brake axle, the rear wheels will be locked, unable to move.

Lift up the rear wheel axle to release the brake, then the stroller can move freely.

**Care and Maintenance**

- To ensure your child from accidental injury, please regularly do the inspection and maintenance of this stroller.
- Please regularly check if there are screws loose, damaged parts or suture breakage. If necessary, replace broken parts.
- When disassembling, carefully follow the operating instructions in order to avoid damage than necessary.
- When cleaning the cloth on the stroller, brush the stain directly with the brush or other cleaning equipment, for other parts cleaning, please use household soap or neutral detergent.

**WARNING**

- Never leave child unattended.
- Avoid serious injury from falling or sliding out. Always use seat belt. Before use, make sure that the stroller has been completely opened and locked in place. Please check whether all the components are connected and locked in place.
- Always apply the brake when the stroller is stopped, even for a brief moment.
- Please do make your child wear seatbelts, do not put your child alone in case of not wearing a seatbelt in the stroller.

- Be careful not let the children stand on the seat.
- Avoid using or storing in a damp, cold or hot environment, keep away from fire or extreme heat.
- Avoid wet, cold or high temperature environments or storage, and a strong heat source of the fire away from the fire.
- Do not carry more than one child in the stroller at a time. The stroller is for children 0-3 years old.
- Maximum load of the stroller: 33LBS
- Storage basket Maximum load 6LBS
- Please DO NOT overweight use, excessive weight may cause a hazardous unstable condition to exist.
- Do not use accessory and spare component part that is not supplied by the manufacturer.
- Please follow all of these instructions to ensure the safety of your child. Keep these instructions for future reference.
- The parcels or accessory items, or both, placed on the unit may cause the unit to become unstable.

**Remove the wheels**



(1) Remove the front wheel: lift up the front part of the stroller with your left hand. Press the above red button. Pull out the front wheels.  
(2) Remove the rear wheel: lift up the rear part of the stroller with your left hand. Press the rear wheel red locking button. Pull out the rear wheels.

**Using the Sleeping basket hook, seat hook**

**Notice**



In order to make the child more comfortable in use, please use sleeping basket and seat hook.

When adjusted to the sleeping status, please connect the iron hook on the frame to the sleeping basket, to make sure the stability of the sleeping basket.