

Trouble	How to solve
Lid opens unusual	Check whether batteries are installed properly according to "+""-" instuction or check whether lithium battery incurs low power, and then re-open the power source switch.
	Check whether sensing area is clean or not, please use neat cloth to wipe if it is dirty.
Lid closes unusual	Check whether electric circuits are damp.If yes,please do not connect power source. You can only use the bin if it is dry.
	Check whether there is any obstacles around the lid.If yes,please remove it.
Lid opens slowly	Dry battery may incur low power, please replace it.
	Lithium battery may incur low power, please charge in time.

NORDIC STYLE

SENSOR TRASH CAN



INSTALLING PROCESS

STEP 1 : TAKE OUT ACCESSORIES

Remove the barrel lid head and flip it over to place it upwards.



STEP 2 : INSTALL 3AA BATTERIES

Unlock the top snap, remove the barrel cover and flip it to the back, find the battery compartment and open the cover, take out the dry battery compartment, put 3 AA batteries into the battery compartment according to + / - instruction, then put back the case and seal the battery cover.



INSTALL LITHIUM BATTERY

Plug one side of the USB cable charger port into the charger port on the side of the rechargeable lithium battery, meanwhile, plug the other side of the USB line into 5V charger to charge. The indicator light on the lithium battery turns red when charging. When charged full, the indicator light will turn green. The lithium battery needs charging for around 4hours to be full power. Finally, take out the inside plastic battery case and put the lithium battery inside, then seal the battery cover.



STEP 3 : OPEN THE POWER SWITCH

Press the power switch at the back side of the lid to "I", the automatic sensor system starts to work.



STEP 4 :

INSTRUCTIONS SENSING FUNCTION

Sensing area is located in the bucket lid dark display diagonally above, when you put the garbage or any part of the body in the sensing area (about 15-25 cm), the bucket lid automatically opens and 5 blue display lights turn on. When leaving the sensing area, the blue light starts to read the seconds and the bucket lid closes automatically in about 5 seconds.



STEP 5 :

TOUCH LONG-OPEN MODE

Press the button on the display, the lid will open automatically and the blue light will rotate, the lid stays open for 5 minutes; press the button again, the lid will close and the light off.



STEP 6 :

INSTRUCTIONS GARBAGE BAGS USE



Unlock the latches on both sides of the bucket, lift the outer bucket upward, put the garbage bag into the inner gray inner bucket, and store the excess bag into the two sides of the storage ring, then put the outer bucket back in and the latches will automatically fasten.

Sorun

Çözüm

Kapak anormal şekilde açılıyor

Pillerin "+" "-" talimatına göre doğru takılıp takılmadığını kontrol edin veya lityum pilin düşük güce neden olup olmadığını kontrol edin ve ardından güç kaynağını yeniden açın

Algılama alanının temiz olup olmadığını kontrol edin, kirli ise silmek için lütfen temiz bir bez kullanın.

Kapak anormal şekilde kapanıyor

Elektrik devrelerinin nemli olup olmadığını kontrol edin, evet ise lütfen güç kaynağını bağlamayın. Çöp kutusunu sadece kuru ise kullanabilirsiniz.

Kapağın etrafında herhangi bir engel olup olmadığını kontrol edin. Varsa, lütfen çıkarın.

Kuru pil düşük güce neden olabilir, lütfen değiştirin.

Kapak yavaş açılıyor

Kuru pil düşük güce neden olabilir, lütfen değiştirin.

Lityum pil düşük güce maruz kalabilir, lütfen zamanında şarj edin.

NORDİK TARZI

SENSÖRLÜ ÇÖP KUTUSU



KURULUM SÜRECİ

ADIM 1 : AKSESUARLARI ÇIKARIN

Varil kapak başlığını çıkarın ve yukarı doğru yerleştirmek için ters çevirin.



ADIM 2 : 3AA PİLLERİ TAKIN

Üst çıkırtın kilidini açın, namlu kapağını çıkarın ve arkaya doğru çevirin, pil bölmesini bulun ve kapağı açın, kuru pil parçasını çıkarın, 3 adet AA pili + / - talimatına göre pil bölmesine yerleştirin, ardından kasayı geri takın ve kapağı kapatın.



LİTYUM PİLİ TAKIN

USB kablo şarj portunun bir tarafını şarj edilebilir lityum pilin yan tarafındaki şarj portuna takın, bu arada USB hattının diğer tarafını şarj etmek için 5V şarj cihazına takın. Şarj olurken lityum pil üzerindeki gösterge ışığı kırmızıya döner. Tam şarj olduğunda, gösterge ışığı yeşile dönecektir. Lityum pilin tam güç olması için yaklaşık 4 saat şarj edilmesi gerekir. Son olarak, içindeki plastik pil kutusunu çıkarın ve lityum pili içine yerleştirin, ardından pil kapağını kapatın.



ADIM 3 : GÜÇ DÜĞMESİNİ AÇIN

Kapağın arka tarafındaki güç düğmesini "I" konumuna getirin, otomatik sensör sistemi çalışmaya başlar.



ADIM 4 :

TALİMAT ALGILAMA FONKSİYONU

Algılama alanı, çöpü veya vücudun herhangi bir kısmını algılama alanına (yaklaşık koyduğunuzda, kova kapağında çapraz olarak yukarıda koyu renkli ekranda bulunur 15-25 cm), kova kapağı otomatik olarak açılır ve 5 mavi ekran ışığı yanar. Algılama alanından çıkarken, mavi ışık saniyeleri okumaya başlar ve kova kapağı yaklaşık 5 saniye içinde otomatik olarak kapanır.



ADIM 5 :

UZUN AÇIK MODUNA DOKUNUN

Ekrandaki düğmeye basın, kapak otomatik olarak açılacak ve mavi ışık dönecektir, kapak 5 dakika açık kalır; düğmeye tekrar basın, kapak kapanacak ve ışık sönecektir.



ADIM 6 :

ÇÖP TORBASİ KULLANIM TALİMATLARI



Kovanın her iki tarafındaki mandalların kilidini açın, dış kovayı yukarı doğru kaldırın. çöp torbasını iç gri iç kovaya koyun ve fazla torbayı saklama halkasının iki tarafına yerleştirin, ardından dış kovayı geri koyun ve mandallar otomatik olarak sabitlenecektir.