




WIRELESS REMOTE CONTROL



USER GUIDE



Buttons



1. Enable alarm: Sets the alarm system to Arm.
2. Disable alarm: Sets the alarm system to Disarm.
3. At Home Alarm: While sensors set to Normal/Perimeter zone type are on, all sensors set to Active zone security type at Home are turned off.
4. Panic Button: It triggers the alarm system instantly, regardless of the alarm status condition.
5. 5- Signal sending LED indicator



Coding

Pairing with the Alarm Panel:

Follow the instructions in the controller/ alarm panel user manual to enter into the configuration/pairing mode, then press any button on the remote control to code/pair.



Technical Data

Battery	3 V DC, CR2032 lithium battery
Static Current	≤ 1uA
Alarm Current	≤ 10mA
Wireless Standard	ASK 433.92 MHz
RF Distance	80m (open space)
Working Environment	-20 °C ~ + 55 °C
Product Size	70x36x11mm

GUARANTEE CARD

Brand Owner:

Name: Ankaref İnovasyon ve Teknoloji A.Ş

Address: ODTÜ Teknokent İkizler Blok, 1.Kat, No:3, 06800 Çankaya ANKARA

Tel: +90 312 299 21 64

Fax: +90 312 224 21 64

e-mail: fonri@fonri.com.tr

Signature:

Stamp:



Seller/Dealer Information:

Name:

Address:

Tel:

Fax:

e-mail:

Invoice Date and No:

Signature:

Stamp:

Product Information

Category: Akıllı Ev ve Otomasyon Sistemleri

Brand: Fonri

Model: YK-11

Warranty Period: 2 year

Service Period: 20 workdays

Serial No:

Authorized Service Providers

Ankaref İnovasyon ve Teknoloji A.Ş

Address: ODTÜ Teknokent İkizler Blok, 1.Kat, No:3, 06800 Çankaya ANKARA

Consumer contact center:

+90 850 307 70 37

e-mail: fonri@fonri.com.tr

WARRANTY POLICY FOR FONRI SMART HOME PRODUCTS

FONRI products are designed and manufactured to the highest standards and deliver high-quality performance, ease of use and ease of installation. If you encounter any difficulties while using your product, we recommend that you first consult the user manual or the information in the support section of this website, where (depending on the product type) you may find a downloadable user manual, frequently asked questions, instruction videos or a support forum.

In the unlikely event of a failure of the product, FONRI will arrange for your FONRI product to be serviced, free-of-charge when you informed us of the defect during the warranty period, provided that the product was used in accordance with the user manual (e.g. in the intended environment).

This document only applies to consumer products. For professional products the warranty terms of the applicable sale or purchase agreement applies.

Warranty period

The warranty period for the product categories mentioned in the heading of this document is 24 months, except where stated otherwise within the user manual.

Warranty terms

The warranty period starts on the date of purchase as stated on your proof-of-purchase and expires at the end of the period indicated in the section "Warranty period" below. If you require service but you have lost your proof-of-purchase, the warranty period shall be deemed to have started three months from the date of manufacture indicated on the product or derived from the serial number. If you require service for products without production date or serial number on the product a valid proof-of-purchase is required.

Where a repair is not possible or not commercially viable, FONRI may replace the product with a new or refurbished product of similar functionality. After a repair, firmware upgrade or replacement the warranty period will continue from the date of the original purchase.

What is excluded?

The warranty does not cover indirect or consequential damages (including but not limited to loss of time, loss of data or loss of income), nor compensation for activities done by yourself, such as regular maintenance, installing firmware updates or saving or restoring data.

FONRI does not warrant uninterrupted or error-free operation of products, including but not limited to, interoperability with all current and/or future versions of software or hardware.

The warranty excludes, or does not apply if:

- The proof-of-purchase has been altered in any way or is made illegible.
- The model number, serial number or production date code on the product has been altered, removed or made illegible.
- The product was purchased as faulty stock.

Repairs or product modifications have been carried out by unauthorized service organizations or persons.

- The defect is the result of excessive use outside the intended purpose.

- The defect is caused by abuse of the product or by environmental conditions that are not in conformance with the user manual of the product.

- The defect is caused by connecting peripherals, additional equipment or accessories (including software) other than those recommended in the user manual.

- The unit has been damaged, including but not limited to damage by animals, lightning, abnormal voltage, fire, natural disaster, transportation or water (unless the user manual expressly states that the product may be rinsed).

Normal wear and tear, or replacement of by their nature consumable parts (e.g. batteries)

- The product does not function properly because it was not originally designed, manufactured or approved for use in the country where you use the product, which might occur when you imported the product.

- The product does not function properly due to problems with access to, or connection with service providers, such as interruptions in the access networks faults on the subscriber's or user's line) and faults in the transmission network (interference, scrambling, faults or poor network quality).

Service needed?

In order to avoid unnecessary inconvenience, we advise you to read the user manual carefully and/or consult the support section of FONRI web site before contacting your dealer or

FONRI. To obtain service within the warranty period please contact the consumer contact centre via one of the contact methods indicated on FONRI web site. When your product is no longer within warranty, in some countries you can contact the nearest authorized service centre directly. If available, you can find the addresses of the service centers on FONRI website.

To be able to help you efficiently when you contact FONRI, its sellers, dealers or service partners please have available:

- The product type- or model number (also sometimes called model ID)

- The proof-of-purchase (e.g. original invoice or cash receipt) indicating the date of purchase, seller/dealer name and model number of the product; and

- The product serial number or production date code as specified on the product where available,

The model number, the serial number or production date code (if available) can be found in the battery compartment or on the back or bottom of the product.

Connected products

All data stored in connected products may be lost or deleted during service and should therefore be properly backup by the customers beforehand. FONRI will not be responsible for any such loss.




KABLOSUZ UZAKTAN KUMANDA



KULLANIM KILAVUZU



Butonlar



1. Alarmı etkinleştir: Alarm sistemini Etkin durumda ayarlar.
2. Alarmı devre dışı bırak: Alarm sistemini Devre Dışı durumuna ayarlar.
3. Evde Alarmı: Normal/Çevre bölge tipine ayarlanan sensörler açıkken, Evde aktif bölge güvenlik tipine ayarlanan tüm sensörler kapatılır.
4. Panik Butonu: Alarm kurulumundan bağımsız olarak alarm sistemini anında tetikler.
5. Sinyal gönderme LED göstergesi



Kodlama

Alarm Paneli ile Eşleştirme:

Kontrol ünitesini konfigürasyon durumuna getirin ve öğrenme komutunu girin (ilgili kılavuza bakın), ardından uzaktan kumandadaki herhangi bir düğmeye basın.



Technical Data

Pil	CR2032 (3V)
Bekleme Akımı	≤ 1uA
Çalışma Akımı	≤ 10mA
Kablosuz Frekansı	RF433MHz
Kablosuz Mesafesi	80m (açık alanda)
Çalışma Sıcaklığı	-20°C ~ + 55°C
Boyutlar	70x36x11mm

GARANTİ BELGESİ

Üretici veya İthalatçı Firmanın:

Ünvanı: Ankaref İnovasyon ve Teknoloji A.Ş.

Adresi: ODTÜ Teknokent İkizler Blok, 1.Kat, No:3, 06800 Çankaya ANKARA

Telefonu: +90 312 299 21 64

Faks: +90 312 224 21 64

e-posta: fonri@fonri.com.tr

Yetkilinin İmzası:

Firmanın Kaşesi:



Satıcı Firmanın:

Ünvanı:

Adresi:

Telefonu:

Faks:

e-posta:

Fatura Tarih ve Sayısı:

Teslim Tarihi ve Yeri:

Yetkilinin İmzası:

Firmanın Kaşesi:

Malın

Cinsi: Akıllı Ev ve Otomasyon Sistemleri

Markası: Fonri

Modeli: YK-11

Garanti Süresi: 2 yıl

Azami Tamir Süresi: 20 iş günü

Seri No:

Authorized Service Providers

Ankaref İnovasyon ve Teknoloji A.Ş.

Address: ODTÜ Teknokent İkizler Blok, 1.Kat, No:3, 06800

Çankaya ANKARA

Consumer contact center:

+90 850 307 70 37

e-mail: fonri@fonri.com.tr

1) Garanti süresi, malın teslim tarihinden itibaren başlar ve 2 yıldır.

Garanti belgesi kâğıt üzerinde yazılı olarak veya kalıcı veri saklayıcısı aracılığıyla verilebilir. Tüketicinin talep etmesi halinde kâğıt üzerinde yazılı olarak verilmesi zorunludur

2) Malın bütün parçaları dahil olmak üzere tamamı garanti

kapsamındadır.

3) Malın ayıplı olduğunun anlaşılması durumunda tüketici, 6502 sayılı Tüketicinin Korunması Hakkında Kanunun 11 inci maddesinde yer alan;

a- Sözleşmeden dönme,

b- Satış bedelinden indirim isteme,

c- Ücretsiz onarılmasını isteme,

ç- Satılanın ayıpsız bir misli ile değiştirilmesini isteme,

haklarından birini kullanabilir.

4) Tüketicinin bu haklardan ücretsiz onarım hakkını seçmesi durumunda satıcı; işçilik masrafı, değiştirilen parça bedeli ya da başka herhangi bir ad altında hiçbir ücret talep etmeksizin malın

onarımını yapmak veya yaptırmakla yükümlüdür. Tüketici ücretsiz onarım hakkını üretici veya ithalatçıya karşı da kullanabilir. Satıcı, üretici ve ithalatçı tüketicinin bu hakkını kullanmasından müteselsilen sorumludur.

5) Tüketicinin, ücretsiz onarım hakkını kullanması halinde malın;

- Garanti süresi içinde tekrar arızalanması,

- Tamiri için gereken azami sürenin aşılması,

- Tamirinin mümkün olmadığının, yetkili servis istasyonu, satıcı,

üretici veya ithalatçı tarafından bir raporla belirlenmesi

durumlarında;

tüketici malın bedel iadesini, ayıp oranında bedel indirimini veya

imkân varsa malın ayıpsız misli ile değiştirilmesini satıcıdan talep

edebilir. Satıcı, tüketicinin talebini reddedemez. Bu talebin yerine getirilmemesi durumunda satıcı, üretici ve ithalatçı müteselsilen sorumludur.

6) Malın tamir süresi 20 iş gününü geçemez. Bu süre, garanti süresi içerisinde mala ilişkin arızanın yetkili servis istasyonuna veya satıcıya bildirim tarihinde, garanti süresi dışında ise malın yetkili servis istasyonuna teslim tarihinden itibaren başlar. Malın arızasının 10 iş günü içerisinde giderilememesi halinde, üretici veya ithalatçı; malın tamiri tamamlanıncaya kadar, benzer özelliklere sahip başka bir malı tüketicinin kullanımına tahsis etmek zorundadır. Malın garanti süresi içerisinde arızalanması durumunda, tamirde geçen süre garanti süresine eklenir.

7) Malın kullanma kılavuzunda yer alan hususlara aykırı kullanılmasından kaynaklanan arızalar garanti kapsamı dışındadır.

8) Tüketici, garantiden doğan haklarının kullanılması ile ilgili olarak çıkabilecek uyuşmazlıklarda yerleşim yerinin bulunduğu veya tüketici işleminin yapıldığı yerdeki Tüketici Hakem Heyetine veya Tüketici Mahkemesine başvurabilir.

9) Satıcı tarafından bu Garanti Belgesinin verilmemesi durumunda, tüketici Ticaret Bakanlığı Tüketicinin Korunması ve Piyasa Gözetimi Genel Müdürlüğüne başvurabilir.